



5. WIRED SETUP




6. PLAY USB OR SD CARD




SUPPORTED AUDIO FILES: MP3, WMA. FAT32 FORMATTED CARD. 32GB MAX.

* not included

7. PHONE CALL



FAQ/TROUBLESHOOTING




FREQUENTLY ASKED QUESTIONS: WWW.TRUST.COM/21715/FAQ

Trust International BV - Laan van Barcelona 600 - 3317DD, Dordrecht, NL


© 14-07-2017 Trust All rights reserved.

Trust
URBAN




USER GUIDE
WIRELESS SPEAKER

1. CHARGE SPEAKER




* not included

2. WIRELESS SETUP 1/2



3. WIRELESS SETUP 2/2



* not included

4. PLAY MUSIC WIRELESS

